

Multi-Purpose Spill Kit Directions

Kit Number: (15201)

Kit Contents:

- Pair of Nitrile Gloves
- Vented Goggles
- Respirator
- Green-Z[®] Solidifier (15oz. Bottle)
- Acid Lock[®] Solidifier (15oz. Bottle)
- Alky[®] Solidifier (15oz. Bottle)
- Petro Lock Absorbent (8oz. Bottle)
- Scoop/Scraper (Quantity: 3)
- Caution Tape Roll
- Drop Cloth
- Zammie[®] Sewer Stopper (Dimensions: 36" x 42")
- Clear Disposal Bags (Quantity: 3 / Dimensions: 30" x 37")
- Twist Ties (Quantity: 3)
- D.O.T. Incident Report Tag
- Instructions

Directions:

1. Determine type of material spilled
2. Notify proper authorities
3. Move and keep people away from accident scene. Use caution barricade tape to isolate area.
4. Do not walk into or touch any spilled material.
5. Avoid inhalation of all gasses, fumes and smoke.
6. Do not assume gasses are harmless because of lack of odor
7. Put on respirator, vented goggles, and gloves
8. If needed place the Zammie[®] Sewer Stopper over any open drain where spill could potentially reach
9. Place neutralizer and solidifying agent in a circle around the spill.
10. Sprinkle remaining neutralizer and solidifying agent over remaining spill.
11. Remove solidified spill with scoop and scraper(s) and carefully place in the proper bag provided. Disposal bag should be chosen dependent upon spill and your local, state and federal regulations.
12. After procedure is completed remove respirator, goggles and gloves....Place all remaining contaminated materials in the red bio-hazard bag.
13. Seal bag with supplied twist tie(s). Fill out proper identification tag(s) and attach. Dispose of bag as required by local, state and federal regulations for Infected solid waste.